




CENTRIFUGAL FAN ARRANGEMENTS


Direct Driven

Arrangement
4




The impeller is mounted directly on the motor shaft.
Motor is placed on a support chair.

Arrangement
5



The impeller is mounted directly on the motor shaft. Motor B5 mounted with its flange without chair support for the motor.


Arrangement
8



The impeller is mounted on a shaft between bearings. Motor and shaft are linked by a semi-elastic coupling.


Belt Driven

Arrangement
9




The impeller is mounted on a shaft between bearings. The motor is mounted on the side of the support chair. The transmission is provided by pulleys and belts.

Arrangement
11



Fan with DOUBLE SUCTION
The impeller is mounted on a shaft between bearings.
The motor is mounted on a common base.
The transmission is provided by pulleys and belts.

Arrangement
12



The impeller is mounted on a shaft between bearings. The motor is mounted on a common base. The transmission is provided by pulleys and belts.